

## **3-WAY MASTER SWITCH (BLACK)**

### **UP ▲**

Turns 12v power ON  
& Lift System OFF  
Position here when trailer is in use.

### **CENTER (NEUTRAL) —**

Turns everything OFF  
except 12v refrigerator  
& breakaway switch  
For storing & traveling

### **DOWN ▼**

Turns Lift System ON  
& 12v power OFF  
For raising or lowering

## **RAISING HI-LO**

- **DOOR CHECK:** Secure top door; hold bottom door out of the way.
- **MASTER SWITCH:** in DOWN position
- **LIFT SYSTEM SWITCH:**  
Hold in UP until trailer is fully raised and you hear the squeal.
- **TEST SAFETY LOCK:**  
Press white switch DOWN, then press UP again to reset.

## **LOWERING HI-LO**

- **TURN OFF LIGHTS, CLEAR COUNTERS, CLOSE WINDOWS**
- **DOOR CHECK:** Secure top door; hold bottom door out of the way.
- **MASTER SWITCH:** in DOWN position
- **LANYARD:** Pull Safety Release Lanyard.
- **LIFT SYSTEM SWITCH:** Hold in DOWN until trailer is fully lowered.