

INSTRUCTIONS FOR OPERATING SLIDE-OUT ROOM

1. RAISE THE HI-LO'S TOP SECTION FROM IT'S TRAVEL POSITION TO FULLY RAISED LIVING POSITION.
2. LOCATE THE KNOB AND LOCKING PLATE ON THE WALL SECTIONS BEHIND THE LOUNGE AND POSITION THE LOCK PLATE OVER THE LOWER SIDE WALL AND TIGHTEN THE KNOB TO SECURE THE TOP SIDE WALL OF THE SLIDE-OUT SECTION. THE DISTANCE BETWEEN THE HEIGHT OF THE SIDES SHOULD BE 1/4 - 3/8 IN. (IT MAY BE NECESSARY TO SLIDE THE ROOM OUT 4-6 IN. TO OBTAIN THIS DISTANCE). IT IS **IMPORTANT** THAT YOU SECURE THE LOCKING PLATE BEFORE YOU EXTEND THE SLIDE OUT SECTION BECAUSE THE TOP OF THE SLIDE-OUT IS SUPPORTED BY THE LOWER SECTION WHEN IN THE SLIDE-OUT POSITION. A RED WARNING LIGHT WILL REMIND YOU THAT THE LOCKING PLATES ARE NOT IN PLACE. (IF THE RED LIGHT COMES ON, DO NOT SLIDE OUT THE ROOM. CHECK TO BE SURE THE LOCKING PLATE IS SECURE).
3. CHECK OUTSIDE THE TRAILER TO BE SURE THERE IS A CLEAR EXTERIOR AREA FOR THE SLIDE-OUT ROOM TO MOVE OUTWARD. THE ROOM MOVES OUTWARD 31".
4. PRESS THE SLIDE-OUT OPERATING SWITCH SO THE ROOM MOVES OUTWARD UNTIL THE WALL FLANGES SEAL AGAINST THE TRAILER'S MAIN WALL (WHEN ROOM IS NEARLY EXTENDED ,RELEASE THE SWITCH AND MOMENTARILY PUSH THE SWITCH TO MAKE THE SEAL). THE SWITCH IS LOCATED ON THE SIDE OF THE CABINET JUST AFT OF THE ENTRANCE DOOR. THE LIFT AND/OR THE SLIDE-OUT SWITCHES WILL NOT OPERATE UNLESS THE MASTER LIGHT SWITCH IS PUSHED TO THE LIFT OPERATION POSITION (LOWER SWITCH POSITION).
5. COVER THE UPPER SLIDE BARS WITH THE CLOTH MATERIAL PROVIDED WITH VELCRO FASTENERS.

TO RETURN THE SLIDE-OUT ROOM REVERSE THE PROCEDURE.

1. REMOVE THE UPPER SLIDE BAR COVERS
2. PUSH THE SLIDE-OUT SWITCH TO RETRACT THE ROOM. RETURN THE ROOM UNTIL THE OUTER WALL FLANGE SEALS AGAINST THE TRAILER'S EXTERIOR WALL.
3. UNDO THE LOCKING PLATED LOCATED IN BACK OF THE LOUNGE BY LOOSENING THE KNOBS AND PLACING THE LOCKING PLATES FLUSH TO THE TOP WALL SO THE PLATES CLEAR THE LOWER WALLS WHEN TOP IS LOWERED. SECURE THE PLATES IN THIS POSITION BY TIGHTENING THE KNOBS (BE SURE THE LOCKING PLATES DEPRESS THE SAFETY SWITCHES).
4. THE TRAILERS TOP SECTION IS NOW READY TO BE LOWERED. IF TOP DOES NOT LOWER, BESURE #3 WAS FOLLOWED CORRECTLY.

NOTE: NEVER LOWER THE TOP WITH THE LOCKING PLATES EXTENDED IN LOCKED POSITION!

NEVER EXTEND THE ROOM UNLESS THE LOCKING PLATES ARE IN LOCKED POSITION!

IN CASE OF FAILURE IN 12V. BATTERY SUPPLY, THERE IS A MANUAL CRANK PROVIDED FOR EMERGENCY USE.

IF YOU ARE USING THE TRAILER IN THE RAISED POSITION AND DO NOT WISH TO SLIDE-OUT THE ROOM, YOU WILL NEED TO INSERT THE TWO FILLER WALL SECTIONS PROVIDED. THESE FILLERS FIT BETWEEN THE SLIDE-OUT AND THE TRAILER EXTERIOR WALLS.

BE SURE THE SWIVEL CHAIR OR ANY OTHER OBJECT IS CLEAR FROM UNDER THE TELEVISION !!