

SETTING UP CAMP

Interior Exterior	Item	Done
E	Select a level site. Note location of utilities and any overhead or side obstacles that would interfere with roof or tip-out. If a pull-thru site, approach from “high side” and line up utilities. Note: 36” of clearance required for tip-out	
E	Level trailer from side-to-side using wood or leveling blocks under wheels	
E	Block wheels with chocks to prevent rolling	
E	Disconnect hitch, if desired. Ensure trailer cord is disconnected prior to raising trailer!	
E	Level trailer front-to-back using power jack	
E	Place black master power switch in lower position	
E	Raise the trailer: 1. Open top door and fasten with door holder. Hold bottom door at 90 degree angle. 2. Press white rocker switch up and hold until top section is fully raised- safety lock should engage automatically. 3. Verify safety lock engaged by depressing white switch down (do not pull cable) Trailer should not lower. 4. Press white switch up momentarily to pressurize hydraulic cylinder. Note: Refer to section 7.9 of owner’s manual for troubleshooting.	
E	Release tip-out straps on left side of trailer	
I	Deploy the tip-out: 1. Place black master switch in lower position 2. Press tip-out toggle switch up- when winch stops, let go of switch immediately 3. Go into coach and push tip-out up until it stops 3. Press tip-out switch down until fully deployed, then let go of switch immediately.	
E	Place black power switch in middle position until plugged in	
E	Plug in electrical cord (if applicable) Wrap one turn around pedestal	
E	Put down stabilizer jacks- make contact w/ground then turn ½ turn more NOTE: Do not use stabilizer jacks for leveling!	
E	Fold out entry steps	
E	Place black power switch in upper position to power trailer DC system	
E	Turn on propane at tank(s)	
I	Turn fridge on in either AC or propane mode, as applicable	
E	Hook up city water, if applicable. Use pressure regulator and filter OR turn on water pump if not hooked up	
I	Ensure hot water heater is filled with water, then turn on with AC, or propane, as desired	
I	Light oven pilot light, if desired	
E	Hook up sewer hose, if applicable. NOTE: keep valves closed until ready to dump, then dump black first and rinse tank with flush water, then dump gray tank.	
E	Open external stove fan vent	
E	Open front window rockguard	
E	Extend awning, if desired	
E	Check camper battery voltage	
I	Open windows and vents	
I	Plug in AC cord, if applicable	