


ADJUSTMENTS

B. Adjusting The Awning Open/Close Limits



- To adjust the awning so the front rail fits tightly against the case when the awning is fully closed:
- Turn the retraction adjustment screw clockwise for less awning retraction.
- Turn the retraction adjustment screw counterclockwise for more awning retraction.



The motor should turn off and stop turning when the awning is fully closed. If the motor continues turning after the awning closes, damage to the motor or awning components may occur.